

General instructions


Cementation of a crown made of Prettau® Anterior

Tools and materials required

- | | | | | | |
|--|--|---|-------------------|---|---------------------------------------|
|  | Sand blaster (aluminium oxide: grain size 110 µm; 3,5 bar) |  | Swab |  | Tool for the removal of excess cement |
|  | Steam jet cleaner |  | Etching gel* |  | Photo-polymerising lamp |
|  | Dry and oil-free compressed air ISO/DIN 7494-2:2014-03 |  | Universal-Primer* |  | Glycerine gel/Airblock* |
|  | Universal-Bonder* |  | Cement* | | |


⚠️ * ATTENTION! Please follow respective instructions of the product manufacturer! Differences are possible due to simplified process description.

Preparation/cleaning of the crown made of Prettau® Anterior



- 1 Sand blast with aluminium oxide (110 µm; 3,5 bar)
- 2 Steam blast
- 3 Dry with compressed air
- 4 Apply Bonder*
- 5 Remove excess with compressed air
- 6 Let it dry (60 secs.)

Pre-treatment/cleaning of the prepared teeth




- 1 Clean and protect the mucosa with a cofferdam
- 2 Apply the etching gel* (37% phosphoric acid)
- 3 Remove carefully with water and vacuum
- 4 Apply Primer*

⚠️ Recommendation for the preparation of the teeth: Clean the teeth and remove plaque. Protect mucosa.

⚠️ * ATTENTION! Please follow respective instructions of the product manufacturer! Differences are possible due to simplified process description.

Cementation of the crown



- 1 Apply the cement*
- 2 Push down firmly and remove the excess cement
- 3 Polymerise (2 secs.) and remove the excess cement
- 4 Apply the glycerine gel/Airblock*
- 5 Polymerise crown on all sides (120 secs.)
- 6 Wash away Airblock excesses